


PRODUCT-DETAILS

# 106/3/1 UC-94-507

## 106/3/1 UC-94-507 Cover Plates

Rocker/button Off switch 3x1-pole with Not included alpine white - Basic55



### General Information

Extended Product Type	106/3/1 UC-94-507
Product ID	2CKA001012A2155
EAN	4011395120767
Catalog Description	106/3/1 UC-94-507 Cover Plates Rocker/button Off switch 3x1-pole with Not included alpine white - Basic55
Long Description	106/3/1 UC-94-507 3G 1W switch

### Technical

Rated Voltage ( $U_r$ )	250 V
Auxiliary Voltage AC/DC	250 V AC/DC
Rated Current ( $I_n$ )	16 A
Maximum Switching Current	Fluorescent Lamps 10 A
Number of Rocker Switches	1
Design Range	Basic55
Wiring Configuration	Off switch 3x1-pole
Actuator Type	Rocker/button
Connection Type	Plug Clamp
Lamp Type	Not included
Mounting Type	Flush Mounted
Surface Finishing	Untreated

	Matt
Material	Thermoplastic
Label Space Provided	No
Illumination	Non-illuminated
Color	alpine white
Battery Weight	0 g
Number of Batteries	0

## Environmental

RoHS Status	Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019
RoHS Information	2CKA200000E0146
REACH Declaration	2CKA309999E9999

## Dimensions

Product Net Width	71 mm
Product Net Height	32 mm
Product Net Depth / Length	71 mm
Product Net Weight	80 g
Built-In Depth (t <sub>2</sub> )	32 mm

## Ordering

Minimum Order Quantity	1 piece
Package Level 1 Units	carton 10 piece
Package Level 1 Gross Weight	0.95 kg
Customs Tariff Number	85365080
Country of Origin	Czech Republic (CZ)

## Certificates and Declarations

Declaration of Conformity - CE	2CKA100000E0055
--------------------------------	-----------------

## Classifications

ETIM 8	EC001590 - Installation switch
ETIM 9	EC001590 - Installation switch
WEEE Category	5. Small Equipment (No External Dimension More Than 50 cm)
WEEE B2C / B2B	Business To Consumer
CN8	8536 50 80
eClass	V11.0 : 27144053

## Accessories

Identifier	Description	Type	Quantity	Unit Of Measure
2CKA001725A1531	2511-91-507 Cover Frame 1gang(s) entrée-grey Horizontal mounting - Basic55	2511-91-507	1	piece
2CKA001725A1484	2511-92-507 Cover Frame 1gang(s) white Horizontal mounting - Basic55	2511-92-507	1	piece

2CKA001725A1501	2511-93-507 Cover Frame 1gang(s) champagne Horizontal mounting - Basic55	2511-93-507	1	piece
2CKA001725A1479	2511-94-507 Cover Frame 1gang(s) alpine white Horizontal mounting - Basic55	2511-94-507	1	piece
2CKA001725A1506	2511-95-507 Cover Frame 1gang(s) château- black Horizontal mounting - Basic55	2511-95-507	1	piece
2CKA001725A1511	2511-96-507 Cover Frame 1gang(s) chalet-white Horizontal mounting - Basic55	2511-96-507	1	piece
2CKA001725A1516	2511-97-507 Cover Frame 1gang(s) foyer-red Horizontal mounting - Basic55	2511-97-507	1	piece
2CKA001725A1521	2511-98-507 Cover Frame 1gang(s) bistro-blue Horizontal mounting - Basic55	2511-98-507	1	piece
2CKA001725A1526	2511-99-507 Cover Frame 1gang(s) maison- beige Horizontal mounting - Basic55	2511-99-507	1	piece
2CKA001725A1532	2512-91-507 Cover Frame 2gang(s) entrée-grey Horizontal mounting - Basic55	2512-91-507	1	piece
2CKA001725A1485	2512-92-507 Cover Frame 2gang(s) white Horizontal mounting - Basic55	2512-92-507	1	piece
2CKA001725A1502	2512-93-507 Cover Frame 2gang(s) champagne Horizontal mounting - Basic55	2512-93-507	1	piece
2CKA001725A1480	2512-94-507 Cover Frame 2gang(s) alpine white Horizontal mounting - Basic55	2512-94-507	1	piece
2CKA001725A1507	2512-95-507 Cover Frame 2gang(s) château- black Horizontal mounting - Basic55	2512-95-507	1	piece
2CKA001725A1512	2512-96-507 Cover Frame 2gang(s) chalet- white Horizontal mounting - Basic55	2512-96-507	1	piece
2CKA001725A1517	2512-97-507 Cover Frame 2gang(s) foyer-red Horizontal mounting - Basic55	2512-97-507	1	piece
2CKA001725A1522	2512-98-507 Cover Frame 2gang(s) bistro-blue Horizontal mounting - Basic55	2512-98-507	1	piece
2CKA001725A1527	2512-99-507 Cover Frame 2gang(s) maison- beige Horizontal mounting - Basic55	2512-99-507	1	piece
2CKA001725A1533	2513-91-507 Cover Frame 3gang(s) entrée-grey Horizontal mounting - Basic55	2513-91-507	1	piece
2CKA001725A1486	2513-92-507 Cover Frame 3gang(s) white Horizontal mounting - Basic55	2513-92-507	1	piece
2CKA001725A1503	2513-93-507 Cover Frame 3gang(s) champagne Horizontal mounting - Basic55	2513-93-507	1	piece
2CKA001725A1481	2513-94-507 Cover Frame 3gang(s) alpine white Horizontal mounting - Basic55	2513-94-507	1	piece
2CKA001725A1508	2513-95-507 Cover Frame 3gang(s) château- black Horizontal mounting - Basic55	2513-95-507	1	piece
2CKA001725A1513	2513-96-507 Cover Frame 3gang(s) chalet- white Horizontal mounting - Basic55	2513-96-507	1	piece
2CKA001725A1518	2513-97-507 Cover Frame 3gang(s) foyer-red Horizontal mounting - Basic55	2513-97-507	1	piece
2CKA001725A1523	2513-98-507 Cover Frame 3gang(s) bistro-blue Horizontal mounting - Basic55	2513-98-507	1	piece
2CKA001725A1528	2513-99-507 Cover Frame 3gang(s) maison- beige Horizontal mounting - Basic55	2513-99-507	1	piece
2CKA001725A1534	2514-91-507 Cover Frame 4gang(s) entrée-grey Horizontal mounting - Basic55	2514-91-507	1	piece
2CKA001725A1487	2514-92-507 Cover Frame 4gang(s) white Horizontal mounting - Basic55	2514-92-507	1	piece
2CKA001725A1504	2514-93-507 Cover Frame 4gang(s) champagne Horizontal mounting - Basic55	2514-93-507	1	piece
2CKA001725A1482	2514-94-507 Cover Frame 4gang(s) alpine white Horizontal mounting - Basic55	2514-94-507	1	piece
2CKA001725A1509	2514-95-507 Cover Frame 4gang(s) château- black Horizontal mounting - Basic55	2514-95-507	1	piece
2CKA001725A1514	2514-96-507 Cover Frame 4gang(s) chalet- white Horizontal mounting - Basic55	2514-96-507	1	piece

2CKA001725A1519	2514-97-507 Cover Frame 4gang(s) foyer-red Horizontal mounting - Basic55	2514-97-507	1	piece
2CKA001725A1524	2514-98-507 Cover Frame 4gang(s) bistro-blue Horizontal mounting - Basic55	2514-98-507	1	piece
2CKA001725A1529	2514-99-507 Cover Frame 4gang(s) maison- beige Horizontal mounting - Basic55	2514-99-507	1	piece
2CKA001725A1535	2515-91-507 Cover Frame 5gang(s) entrée-grey Horizontal mounting - Basic55	2515-91-507	1	piece
2CKA001725A1488	2515-92-507 Cover Frame 5gang(s) white Horizontal mounting - Basic55	2515-92-507	1	piece
2CKA001725A1505	2515-93-507 Cover Frame 5gang(s) champagne Horizontal mounting - Basic55	2515-93-507	1	piece
2CKA001725A1483	2515-94-507 Cover Frame 5gang(s) alpine white Horizontal mounting - Basic55	2515-94-507	1	piece
2CKA001725A1510	2515-95-507 Cover Frame 5gang(s) château- black Horizontal mounting - Basic55	2515-95-507	1	piece
2CKA001725A1515	2515-96-507 Cover Frame 5gang(s) chalet- white Horizontal mounting - Basic55	2515-96-507	1	piece
2CKA001725A1520	2515-97-507 Cover Frame 5gang(s) foyer-red Horizontal mounting - Basic55	2515-97-507	1	piece
2CKA001725A1525	2515-98-507 Cover Frame 5gang(s) bistro-blue Horizontal mounting - Basic55	2515-98-507	1	piece
2CKA001725A1530	2515-99-507 Cover Frame 5gang(s) maison- beige Horizontal mounting - Basic55	2515-99-507	1	piece
2CKA001726A0222	2516-901-507 Decorative Styling Frame attica / pigeon blue - Basic55	2516-901-507	1	piece
2CKA001726A0223	2516-902-507 Decorative Styling Frame silver metallic - Basic55	2516-902-507	1	piece
2CKA001726A0224	2516-903-507 Decorative Styling Frame light green - Basic55	2516-903-507	1	piece
2CKA001726A0225	2516-904-507 Decorative Styling Frame orange - Basic55	2516-904-507	1	piece
2CKA001726A0226	2516-905-507 Decorative Styling Frame yellow - Basic55	2516-905-507	1	piece
2CKA001726A0227	2516-906-507 Decorative Styling Frame apricot - Basic55	2516-906-507	1	piece
2CKA001726A0228	2516-907-507 Decorative Styling Frame luminous - Basic55	2516-907-507	1	piece
2CKA001726A0220	2516-92-507 Decorative Styling Frame white - Basic55	2516-92-507	1	piece
2CKA001726A0230	2516-93-507 Decorative Styling Frame champagne - Basic55	2516-93-507	1	piece
2CKA001726A0218	2516-94-507 Decorative Styling Frame alpine white - Basic55	2516-94-507	1	piece
2CKA001726A0232	2516-95-507 Decorative Styling Frame château- black - Basic55	2516-95-507	1	piece
2CKA001726A0234	2516-96-507 Decorative Styling Frame chalet- white - Basic55	2516-96-507	1	piece

---

## Categories

---

Low Voltage Products and Systems → Switch Assortments → Cover Plates → Switch & Push Buttons

