



 PRODUCT-DETAILS

2115-94-507

Electronic Controls for Dimmer Turn button alpine white - Basic55



General Information

Extended Product Type	2115-94-507
Product ID	2CKA006599A2928
EAN	4011395090886
Catalog Description	Electronic Controls for Dimmer Turn button alpine white - Basic55
Long Description	For Busch-Dimmer®. For inserts 2112 U-101/2247 U/2250 U/6513 U-102/6517 U-10x/6519 U/6520 U/6523 U(R)(10x) /6591 U-10x and 6592 U.

Installation

Instructions and Manuals	No document needed
Mounting Type	Flush Mounted
Type of Fastening	Screw

Environmental

Degree of Protection	IP20
----------------------	------

Technical

Data Sheet, Technical Information	No document needed
Application	Dimmer

Design

Design Range	Basic55
Surface Finishing	Untreated Glossy
Material	Thermoplastic
RAL Number	RAL 9010 - Pure White
Color	alpine white

Dimensions

Product Net Width	55 mm
Product Net Height	55 mm
Product Net Depth / Length	21 mm
Product Net Weight	19.5 g

Material Compliance

RoHS Information	2CKA200000E6063
RoHS Status	Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019
REACH Declaration	2CKA309999E9999
REACH Information	False - does not contains substances > 0.1 mass percentage
Conflict Minerals Reporting Template (CMRT)	9AKK108468A3363

Certificates and Declarations

Declaration of Conformity - CE	2CKA200000E6063
--------------------------------	-----------------

Classifications

ETIM 9	EC000011 - Control element/cover plate for domestic switching devices
eClass	V11.0 : 27144002
WEEE Category	5. Small Equipment (No External Dimension More Than 50 cm)
WEEE B2C / B2B	Business To Consumer

Accessories

Identifier	Description	Type	Quantity	Unit Of Measure
2CKA006599A2035	Busch-Rotary-Dimmer Insert Turn button 230 V	2112 U-101	1	piece
2CKA006520A0226	Busch-Rotary-Dimmer Insert Turn/push button 230 V 200...800 V-A	6520 U	1	piece

2CKA001725A1531	Cover frame 1gang entrée grey - Basic55	2511-91-507	1	piece
2CKA001725A1484	Cover frame 1gang white - Basic55	2511-92-507	1	piece
2CKA001725A1501	Cover frame 1gang champagne - Basic55	2511-93-507	1	piece
2CKA001725A1479	Cover frame 1gang alpine white - Basic55	2511-94-507	1	piece
2CKA001725A1506	Cover frame 1gang château-black - Basic55	2511-95-507	1	piece
2CKA001725A1511	Cover frame 1gang chalet white - Basic55	2511-96-507	1	piece
2CKA001725A1516	Cover frame 1gang foyer red - Basic55	2511-97-507	1	piece
2CKA001725A1521	Cover frame 1gang bistro-blue - Basic55	2511-98-507	1	piece
2CKA001725A1526	Cover frame 1gang maison-beige - Basic55	2511-99-507	1	piece
2CKA001725A1532	Cover frame 2gang entrée grey - Basic55	2512-91-507	1	piece
2CKA001725A1485	Cover frame 2gang white - Basic55	2512-92-507	1	piece
2CKA001725A1502	Cover frame 2gang champagne - Basic55	2512-93-507	1	piece
2CKA001725A1480	Cover frame 2gang alpine white - Basic55	2512-94-507	1	piece
2CKA001725A1507	Cover frame 2gang château-black - Basic55	2512-95-507	1	piece
2CKA001725A1512	Cover frame 2gang chalet white - Basic55	2512-96-507	1	piece
2CKA001725A1517	Cover frame 2gang foyer red - Basic55	2512-97-507	1	piece
2CKA001725A1522	Cover frame 2gang bistro-blue - Basic55	2512-98-507	1	piece
2CKA001725A1527	Cover frame 2gang maison-beige - Basic55	2512-99-507	1	piece
2CKA001725A1533	Cover frame 3gang entrée grey - Basic55	2513-91-507	1	piece
2CKA001725A1486	Cover frame 3gang white - Basic55	2513-92-507	1	piece
2CKA001725A1503	Cover frame 3gang champagne - Basic55	2513-93-507	1	piece
2CKA001725A1481	Cover frame 3gang alpine white - Basic55	2513-94-507	1	piece
2CKA001725A1508	Cover frame 3gang château-black - Basic55	2513-95-507	1	piece
2CKA001725A1513	Cover frame 3gang chalet white - Basic55	2513-96-507	1	piece
2CKA001725A1518	Cover frame 3gang foyer red - Basic55	2513-97-507	1	piece
2CKA001725A1523	Cover frame 3gang bistro-blue - Basic55	2513-98-507	1	piece
2CKA001725A1528	Cover frame 3gang maison-beige - Basic55	2513-99-507	1	piece
2CKA001725A1534	Cover frame 4gang entrée grey - Basic55	2514-91-507	1	piece
2CKA001725A1487	Cover frame 4gang white - Basic55	2514-92-507	1	piece
2CKA001725A1504	Cover frame 4gang champagne - Basic55	2514-93-507	1	piece
2CKA001725A1482	Cover frame 4gang alpine white - Basic55	2514-94-507	1	piece
2CKA001725A1509	Cover frame 4gang château-black - Basic55	2514-95-507	1	piece
2CKA001725A1514	Cover frame 4gang chalet white - Basic55	2514-96-507	1	piece
2CKA001725A1519	Cover frame 4gang foyer red - Basic55	2514-97-507	1	piece
2CKA001725A1524	Cover frame 4gang bistro-blue - Basic55	2514-98-507	1	piece
2CKA001725A1529	Cover frame 4gang maison-beige - Basic55	2514-99-507	1	piece
2CKA001725A1488	Cover frame 5gang white - Basic55	2515-92-507	1	piece
2CKA001725A1505	Cover frame 5gang champagne - Basic55	2515-93-507	1	piece
2CKA001725A1483	Cover frame 5gang alpine white - Basic55	2515-94-507	1	piece
2CKA001725A1510	Cover frame 5gang château-black - Basic55	2515-95-507	1	piece
2CKA001725A1515	Cover frame 5gang chalet white - Basic55	2515-96-507	1	piece
2CKA001725A1525	Cover frame 5gang bistro-blue - Basic55	2515-98-507	1	piece
2CKA001725A1530	Cover frame 5gang maison-beige - Basic55	2515-99-507	1	piece
2CKA001726A0222	Decorative Styling Frame attica / pigeon blue - Basic55	2516-901-507	1	piece
2CKA001726A0223	Decorative Styling Frame silver metallic - Basic55	2516-902-507	1	piece
2CKA001726A0224	Decorative Styling Frame light green - Basic55	2516-903-507	1	piece
2CKA001726A0225	Decorative Styling Frame orange - Basic55	2516-904-507	1	piece
2CKA001726A0226	Decorative Styling Frame yellow - Basic55	2516-905-507	1	piece
2CKA001726A0227	Decorative Styling Frame apricot - Basic55	2516-906-507	1	piece
2CKA001726A0228	Decorative Styling Frame luminous - Basic55	2516-907-507	1	piece
2CKA001726A0220	Decorative Styling Frame white - Basic55	2516-92-507	1	piece
2CKA001726A0230	Decorative Styling Frame champagne - Basic55	2516-93-507	1	piece

2CKA001726A0218	Decorative Styling Frame alpine white - Basic55	2516-94-507	1	piece
2CKA001726A0232	Decorative Styling Frame château-black - Basic55	2516-95-507	1	piece
2CKA001726A0234	Decorative Styling Frame chalet white - Basic55	2516-96-507	1	piece

Categories

Low Voltage Products and Systems → Wiring Accessories - Light Switch Ranges → Cover Plates and Control Elements → Electronic Controls

